



# **SD7K**

## **DIGITAL DRUM KIT**

## **USER MANUAL**



#### FCC Statements

1. Caution: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
2. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
  - Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a different circuit.
  - Consult an experienced radio/TV technician for help.

# CONGRATULATIONS!

**... on your purchase of the Simmons SD7K Electronic Drum Kit. To get the most enjoyment from it, we recommend that you skim through this manual at least once, then refer back to it often to learn more about specific functions.**

## Taking Care of Your Digital Drum Set

### Location

- To avoid deformation, discoloration, or more serious damage, do not expose the unit to direct sunlight, high temperature sources, or excessive humidity.

### Power Supply

- Turn the power switch OFF when the SD7K is not in use.
- The AC adapter should be unplugged from the AC outlet if the SD7K is not to be used for an extended period of time.
- Avoid plugging the AC adapter into an AC outlet that is also powering high-consumption appliances such as electric heaters or televisions. Also avoid using multi plug adapters since these can reduce sound quality, cause operation errors and result in possible damage.
- To avoid damage, turn OFF the SD7K's power switch and all related devices prior to connecting or disconnecting cables.

### Handling and Transport

- Never apply excessive force to controls, connectors, and other parts.
- Unplug cables by gripping the plug firmly. Do not pull on the cable.
- Disconnect all cables before moving the module.
- Physical shocks caused by dropping, bumping, or placing heavy objects on the module can result in scratches and more serious damage.

### Cleaning

- Clean the module with a dry, soft cloth.
- A slightly damp cloth may be used to remove stubborn grime and dirt.
- Never use cleaners such as alcohol or thinner.
- To avoid discoloration, do not place vinyl objects on top of module.

### Electrical Interference


- The module contains digital circuitry and may cause interference if placed too close to radio or television receivers. If this occurs, move the SD7K further away from the affected equipment.

### Service and Modification

- There are no user serviceable parts in the drum module.
- Do not attempt to open the drum module or make any change in the circuits or parts of the unit. This would void the warranty.

# SD7K SETUP

Setup your SD7K kit following the included assembly instruction sheet.




# TABLE OF CONTENTS

<b>Panels</b>	<b>4</b>
Top Panel	4
Rear Panel	5
Side Panel	5
<b>Connections</b>	<b>6</b>
Pads and Pedals	6
Audio Equipment	7
Headphones	7
MP3/CD Player	7
Power Supply	7
Power Switch	7
<b>Using the SD7K Pads</b>	<b>8</b>
Playing the Pads	8
Metronome	8
<b>Kit Mode</b>	<b>9</b>
Selecting a Drum Kit	9
Global reverb	9
<b>Voice Mode</b>	<b>10</b>
Selecting the Drum Voice	10
Adjusting Pad Level	11
Adjusting Pad Pan	11
Adjusting Pad Tuning	11
Saving User Kits	11
<b>Utility Menu</b>	<b>12</b>
Pad Sensitivity (Gain)	12
Rim Sensitivity	12
Crosstalk	12
Curve	13
Splash Sensitivity	13
Local Mode	13
Saving Trigger Settings	13
Restoring the Factory Preset	13
<b>Song Mode</b>	<b>14</b>
Selecting a Song	14
Listening to a Song	14
Muting the Drum Part	14
Accompaniment Volume	15
Drum Volume	15
Song Source	15
Song Tempo	15
<b>MIDI and USB</b>	<b>16</b>
MIDI Connection	16
USB Connection	16
Local Mode	16
MIDI Channels	16-17
<b>Voice List</b>	<b>18</b>
<b>Drum Kit List</b>	<b>20</b>
<b>Song List</b>	<b>20</b>
<b>General MIDI Voice List</b>	<b>21</b>
<b>Percussion Set List</b>	<b>22</b>
<b>MIDI Implementation Chart</b>	<b>24</b>

## PANELS

## TOP PANEL

**1 Master volume knob**

Controls the volume of phone and line outputs.

**2 Pad select buttons and indicators**

In Kit mode, the buttons can play the pad voices. In Voice Mode, they select the pad to be edited and the indicators show the current selected pad. In Song Mode, the indicators will display which pads are being played by the drum track.

**3 [TEMPO+] button, [TEMPO-] button**

Changes current tempo.

**4 [CLICK] button and indicator**

Turns the metronome on or off and selects the metronome sound (click or voice).

**5 [DRUM OFF] button and indicator**

Mutes the drum part of the Song.

**6 [START/STOP] button**

Starts and stops the selected song.

**7 [SONG] button**

Enters or switches Song menu pages.

**8 3-digit LED**

This LED is the main display device of the SD7K, which will show the parameters of the current menu.

**9 [VOICE] button**

Enters or switches Voice menu pages.

**10 [KIT] button**

Enters or switches Kit menu pages.

**11 [UTILITY] button**

Enters or switches Utility menu pages.

**12 [+] button, [-] button**

Changes values (kit number, voice number, song number, etc.) when editing.

**13 [SAVE] button**

This button is used to save the current kit settings in a user kit and saves the trigger settings under the Utility menu pages.

## REAR PANEL

### 14 Pad input jacks

Input connections for kick, snare, tom, cymbal pads and hi-hat control pedal.

### 15 Line output jacks


Stereo output connection to an audio system or drum amplifier such as the Simmons DA50 or DA200S.

### 16 AUX input jack

This stereo input jack is for an external sound source such as an MP3 or CD player.

### 17 DC input

Connection for the DC 9V power adapter



## SIDE PANEL

### 18 Power switch

This switch turns power on and off.

### 19 MIDI IN and OUT


These ports allow communication with other products equipped with a MIDI interface. Please see the MIDI section of this manual for details.

### 20 USB port

This port is used to connect to a computer. (MIDI In/Out via USB)

### 21 Phone jack

This stereo jack is used to connect headphones.



# CONNECTIONS



## PADS AND PEDALS

### CAUTION!

To avoid damage, turn OFF the SD7K's power switch and all related devices prior to connecting or disconnecting cables.

#### Pads and Pedals:


Using the provided cables, connect each pad to its corresponding trigger input jack, following the marking on the cables. Secure all the cables to the stand using the provided velcro strips.






## AUDIO EQUIPMENT

When using an amplifier such as the Simmons DA50 or DA200S, connect the Output **L/MONO** and **R** jacks on the rear panel to the input of the amplifier. (For mono playback, use the **L/MONO** jack; for stereo playback, connect both **L/MONO** and **R** jacks.)




## HEADPHONES

An optional set of stereo headphones can be connected to the **PHONES** jack located on the side of the drum module.



## MP3/CD PLAYER

1. Connect the audio output of an MP3/CD player or other audio source to the stereo **AUX IN** TRS jack on the rear panel.
2. The input signal is mixed with the drum signal, allowing you to play along.




## POWER SUPPLY

Make sure the power is switched **OFF**.  
Connect the power adapter to the **DC IN** jack on the rear panel.

**NOTE:**


Make sure the power is switched **OFF** when connecting the drum module with external devices.



## POWER SWITCH

After confirming that all connections have been completed, rotate the volume knob to the left (minimum volume level) before switching the power on.

Set the power switch to the "ON" position. The kit indicator will light up and the display will show kit number 001.



# USING THE SD7K PADS

## PLAYING THE PADS

- All the drum pads and cymbal pads use a single trigger sensor for the whole pad, except the dual-zone snare pad that uses one trigger for the head and another trigger for the rim.
- All the pads are velocity sensitive. Some voices can change sounds depending on the velocity level (striking force).
- The trigger area of the cymbal pads (ride, crash or hi-hat) is near the edge of the pad.
- Similar to an acoustic drum kit, the Hi-Hat sound varies depending on the position of the pedal (Hi-Hat Control):
  - Open Hi-Hat: Strike the hi-hat pad without pressing the pedal
  - Half Open Hi-Hat: Strike the hi-hat pad with the pedal pressed half-way
  - Closed Hi-Hat: Strike the hi-hat pad with the pedal pressed all the way down
  - Foot Close: Press the pedal all the way down
  - Splash: Step fully on the pedal and release it immediately

## METRONOME

The SD7K includes a Metronome feature with two types of sounds: Click (Bell sound on the first beat, and click sound on the other beats) or Vocal Counting ("one", "two", "three", "four", ...).

Press the **[CLICK]** button to start the metronome with Click sound.

Press the **[CLICK]** button a second time to change the metronome to Vocal Counting.

Press the **[CLICK]** button again to stop the metronome.

While the metronome is playing, the Beat indicator flashes at the current tempo.

While the metronome is playing, the LED shows the current time signature.

The time signature of the metronome can be changed using the **[+]** and **[-]** buttons.



There are five available options: 2/4, 3/4, 4/4, 5/4 and 6/8.

The SD7K returns to the previous display when the metronome is stopped.

Press the **[Tempo +]** or **[Tempo -]** buttons to change the tempo (30 ~ 280). The LED shows the current tempo and returns to the previous display after about 2 seconds if there is no operation of the Tempo **[+]** and **[-]** buttons.

The volume of the metronome can be adjusted by holding down the **[CLICK]** button and pressing the **[+]** or **[-]** buttons. The LED shows "Cxx" (xx = metronome volume: 0 ~ 16), and returns to the previous display about 2 seconds after releasing the **[CLICK]** button. The metronome volume resets to its default value when turning off the SD7K.



Beat indicator



# KIT MODE

If the SD7K is not yet in KIT Mode, Press the **[KIT]** button to enter the Kit Mode. The Kit indicator will light up.

In the KIT Mode, you can select the Drum or Percussion Kit to play. You can also turn on or off the Reverb effect.



## SELECTING A DRUM KIT

In the Kit Number page, the 3-digit LED shows the current kit number. Use the **[+]** and **[-]** buttons to select any kit (1 ~ 50, looped) as the current kit.

The SD7K includes 20 factory preset kits (1 ~ 20) and 30 User kits (21 ~ 50). (See Kit List on page 20.)

Note: In KIT mode, you can use the Pad Select buttons to play the voices associated with the pads of the currently selected kit.




## GLOBAL REVERB

When the SD7K is in the Kit Number page, press the **[KIT]** button again to access the Global Reverb page.

In the Global Reverb page, the LED shows the current Reverb status ("roN" for Reverb On or "roF" for Reverb Off). It can be turned On or Off using the **[+]** or **[-]** buttons.


Press the **[KIT]** button again to return to the Kit Number page.



# VOICE MODE


If the SD7K is not yet in VOICE Mode, press the **[VOICE]** button to enter the Voice Menu. The Voice indicator lights up. Now the **[VOICE]** button will page through the Voice Menu.

In the VOICE Mode, you can select the voice for each pad and adjust the level, pan and tuning of the pad.



The current pad to be edited can be selected either by pressing its Pad Select button, or by striking the pad itself. The Pad Select indicator lights up to show which pad is currently selected.

Note: While editing voice number, level, pan and tuning, you can also preview the result of the current settings by pressing the Pad Select button to play the edited voice.



## SELECTING THE DRUM VOICE

In the Voice Number page, the 3-digit LED shows the current voice number for the selected pad. Use the **[+]** and **[-]** buttons to select any voice (1 ~ 300, looped) for the current pad. The SD7K includes 300 voices sorted by category (Kick, Snare, Tom, Cymbal, Hi-Hat, Percussions). Each category includes a variety of acoustic, electric and effects voices. (See Voice List on pages 18-19.)

**NOTE:** The voices for the snare head and rim are set independently. When the snare pad is selected, press the Rim button to select the snare rim (or strike the rim of the snare pad). The voices for the hi-hat (Open, Half, Closed, Foot and Splash) are selected together as a single voice number (voices # 237 ~ 252) which will contain all the variations.



## ADJUSTING PAD LEVEL

Press the **[VOICE]** button until the LED display shows "Lxx". (xx = Level value: 0 ~ 32)  
Use the **[+]** and **[-]** buttons to adjust the level of the current pad.




## ADJUSTING PAD PAN

Press the **[VOICE]** button until the LED display shows "Pxx". (xx = Pan value: -8 ~ +8)  
Use the **[+]** and **[-]** buttons to adjust the Pan of the current pad.



## ADJUSTING PAD TUNING

Press the **[VOICE]** button until the LED display shows "txx". (xx = Tuning value: -8 ~ +8)  
Use the **[+]** and **[-]** buttons to adjust the tuning of the current pad.



## SAVING USER KITS

Make sure you save your customized kit; otherwise, your changes will be lost when you select another kit or turn off the SD7K.


Kits 001 ~ 020 are factory presets. Customized kits can be saved in User kits 021 ~ 050.

User kits store all the voice settings (voice number, level, pan and tuning) for all the pads.

To save your customized kit to one of the User kits:

1. Press the **[SAVE]** button. The kit number flashes on the LED.
2. Use the **[+]** or **[-]** buttons to set the User kit number (021 ~ 050).  
The kit number will still be flashing.
3. Press the **[SAVE]** button again. The kit number stops flashing and the SD7K returns to Kit Mode.


**NOTE:** To cancel the save operation while the LED is flashing, press the **[KIT]** or **[VOICE]** button.




# UTILITY MENU

Press the **[UTILITY]** button to enter the Utility Mode. Now the **[UTILITY]** button will page through the Utility menu.

In the **UTILITY** Mode, you can adjust the trigger parameters (gain, crosstalk, curve) for each pad, as well as the rim sensitivity of the snare pad and the splash sensitivity of the hi-hat control pedal. Those parameters are common to all kits.



The current pad to be adjusted can be selected either by pressing its Pad Select button, or by striking the pad itself. The Pad Select indicator lights up to show which pad is currently selected.



## PAD SENSITIVITY (GAIN)

In the Trigger Gain page, the first digit of LED will display letter 'E', which is followed by the gain value (1~16, not looped). Greater gain will allow you to trigger a signal even if you strike a pad lightly.



## RIM SENSITIVITY

In the Rim Sensitivity page, rim sensitivity of the dual trigger snare pad can be adjusted to balance the head-rim velocities. The lowest digit will show the rim sensitivity level (1~8) of current pad with letters 'rE' displayed on the first two digits of the LED. A bar will be shown instead of the sensitivity level if rim triggering is not supported by the currently selected pad (any other pad than the snare).




## CROSSTALK

In the Trigger Crosstalk page, the last 2 digits will show the crosstalk value (1~16) of the current pad with a letter 'o' displayed on the first digit of the LED. Hitting one pad may trigger the sound from another pad unintentionally. This effect can be eliminated by setting this parameter to a higher value on the pad that is mistriggering.




## CURVE

In the Velocity Curve page, the curve setting allows you to control the relationship between the velocity (striking force) and loudness (the dynamic curve). The last digit will show the curve number (1~6) of the current pad with letters 'CU' displayed on the first two digits of the LED.



## SPLASH SENSITIVITY



In the Splash Sensitivity page, this setting controls the sensitivity of the foot splash. The data is from -4 to 4 with 'F' displayed on the first digit of LED.



## LOCAL MODE

In local control page, the LED shows the local control mode. Local ON is the default function mode ('LoN'). The internal link between pad triggers and sound generator will be broken when selecting Local OFF ('LoF'). For more details regarding the Local Mode, please see the MIDI /USB section of this manual.

**NOTE:** Local control mode always returns to Off when powering up the SD7K.



## SAVING TRIGGER SETTINGS

After adjusting the trigger settings (gain, snare rim sensitivity, crosstalk, curve, splash sensitivity), you can save them into memory. While in the Utility mode, press the **[SAVE]** button to store all trigger settings.

**NOTE:**

1. If you turn off the power without saving, you will lose the trigger setting changes you have just made.
2. These parameters affect all kits.



## RESTORING THE FACTORY PRESET



Restoring the factory preset can be implemented by the following operation: Hold down both **TEMPO+** and **TEMPO-** when the SD7K is powered up. This function will replace the current settings of the following parameters by their default preset values:

- All user kits (including volume, voice, pan, reverb, and tuning setting)
- Utility parameters (including gain, crosstalk, curve and splash sensitivity)

# SONG MODE

If the SD7K is not yet in SONG Mode, press the **[SONG]** button to enter the Song Menu. Now the **[SONG]** button will page through the Song Menu. The Song indicator lights up.

In the SONG Mode, you can select the song number, and adjust the volume of the song's accompaniment and drum part. In addition, you can select whether to use the internal songs or to control an external sequencer.



## SELECTING A SONG

In Song Number page, the 3-digit LED shows the current song number.

Use the **[+]** and **[-]** buttons to select any song (1 ~ 50, looped) as the current Song. The SD7K includes 50 factory preset songs. (See Song List on page 20.)




## LISTENING TO A SONG

Press the **[START/STOP]** button to start song playback. The beat indicator will flash at the song tempo. After count-in, the song will start playback from the beginning. The song will stop when it reaches the end. You can also stop the song during playback by pressing the **[START/STOP]** button again.

If the song number is switched while playing, the new song won't start until the end of the current bar.

During song playback in song menu, the Pad indicators will show which pads the drum track is triggering. This function can be disabled or enabled by pressing the **[KICK]** button while in song mode.




## MUTING THE DRUM PART

Press **[DRUM OFF]** to enable or disable the drum mute function.

When drum off is enabled, the DRUM OFF indicator will light up, and the drum track from the current playing song will be muted. In Song mode, the Pad indicators will still show the pads played by the drum track. This allows you to practice playing the drum part with the rest of the accompaniment.

To help you play together with the song, you can also enable the metronome function by pressing the **[CLICK]** button. (See Metronome function for details.)





## ACCOMPANIMENT VOLUME

Press the **[SONG]** button until the LED display shows "Axx" (xx = accompaniment volume, 0 ~ 32).

Use the **[+]** and **[-]** buttons to adjust the song's accompaniment volume (all instruments except the drum part). It will be restored to default value on the next power on.



## DRUM VOLUME

Press the **[SONG]** button until the LED display shows "dxx" (xx = drums part volume, 0 ~ 32).

Use the **[+]** and **[-]** buttons to adjust the song's drum volume. It will be restored to default value on the next power on.



## SONG SOURCE

In song source selection page, the LED will show the current selected song source. There are two choices: "LoC" for local machine (50 internal songs, default setting) or "EtN" for controlling an external sequencer connected to the MIDI Out of the SD7K using MIDI Clock. See the MIDI section of the manual for details.

Use the **[+]** and **[-]** to select the song source. Song playing will stop immediately when switching song source.

When External is selected, press **[START/STOP]** to start or stop the external sequencer with corresponding MIDI real-time messages. The internal song will not playback.


NOTE: If external sequencer is selected as current song source, the menu pages of song number, accompaniment volume and drum volume will be not selectable.



## SONG TEMPO

Press the **[TEMPO+]** or **[TEMPO-]** buttons to display the current tempo. Use **[TEMPO+]** and **[TEMPO-]** buttons to adjust the tempo. Press both **[TEMPO+]** and **[TEMPO-]** buttons at the same time to reset the current tempo to its default value for the current song. (This function is not available when external song is selected.)

If there's no operation, SD7K will return to the previous menu page automatically after 2 seconds.



## MIDI AND USB

MIDI stands for Musical Instrument Digital Interface. This is a world-wide standard communication interface that enables electronic musical instruments and computers (of all brands) to communicate with each other so that instructions and other data can pass between them. This exchange of information makes it possible to create a system of MIDI instruments and devices that offer far greater versatility and control than is available with isolated instruments. Whether you interface with computers, sequencers, expanders or other controllers, your musical horizons will be greatly enhanced.

### MIDI CONNECTION

**MIDI IN:** This terminal receives MIDI data from an external MIDI device.

**MIDI OUT:** This terminal transmits data from this instrument to other MIDI devices.

### USB CONNECTION

The USB connector allows you to connect the SD7K directly to your computer. It can be connected without driver installation under the Windows XP & MAC OSX environment. The SD7K will be recognized as "USB Audio device" to receive and transmit MIDI messages through a single USB cable. USB is used only for MIDI messages (MIDI via USB).

**NOTE:** When the USB is connected to a computer, all MIDI messages will be received and transmitted via USB.

### LOCAL MODE

From a MIDI point of view, the SD7K is composed of two "devices":

- A controller transmitting data: the pads and hi-hat control pedal (via an internal trigger to MIDI converter)
- A sound generator receiving MIDI data (the sound module).

In normal operation (Local ON, default mode), those two devices are connected together internally, allowing the pads to play the voices from the sound module without any external connection. When setting Local mode to Local OFF mode in the Utility menu, this internal link is disconnected. The sound module receives MIDI messages via MIDI input only, not from the pads anymore. However, the pad trigger data is still sent to the MIDI Output, therefore looping externally the MIDI Out of the SD7K back to its MIDI In will enable the pads to play the voices from the sound module. Local OFF mode is intended to be used when both the MIDI input and output (or the USB port) of the SD7K are connected to a MIDI sequencer with Soft Thru function (which loops the MIDI data received from the MIDI output back to the MIDI input). This prevents doubling or flanging effect when playing the pads (caused by the sound generator receiving the same MIDI data both directly from the pads and back through the sequencer).

### MIDI CHANNELS

The SD7K transmission channel is fixed to Channel 10 (Drums and Percussion channel). The SD7K will output MIDI codes generated by the triggers when hitting the pads or stepping on the Hi-hat control pedal (Program Change, Note On/Off, and Foot Control messages). Song playback data and metronome notes are not transmitted.

The MIDI system in the SD7K has 16 reception channels numbered from 1-16. Each of the channels is responsible for a voice. When the instrument receives MIDI information from an external device, the active channel is determined by the control message. Channel 10 is reserved for the Drums. Channels 9 and 16 can be used for additional Percussion sounds. (See Percussion Set list pages 22-23.) All other channels (1-8, 11-15) can be used to access the 128 General MIDI instruments and sounds included in the sound module (GM standard). These are the same instruments that are used to create the accompaniment for the internal Song player.

### Using the SD7K as a General MIDI sound module

Connecting an external keyboard or sequencer to the MIDI Input allows you to use the SD7K as a multi-timbral sound module to play various instrument parts in addition to your drums (for instance, Piano on Channel 1, Bass on Channel 2, Strings on Channel 3, etc). The voices on each MIDI channel are selected using MIDI Program Change messages. (See the General MIDI Voice list page 21.)  
NOTE: For more information on received MIDI messages, see the MIDI implementation chart.

### Using the SD7K to control a sequencer

In Song mode, the song source can be set to External, allowing the SD7K to control the playback of an external sequencer. MIDI clock (0xF8) is sent out automatically at the current tempo, and Start and Stop Real-Time Commands (0xFA, 0xFC) will be sent when pressing the Start/Stop button.

1. Connect the MIDI Out of the SD7K to the MIDI In of your sequencer. If you are using a software sequencer on a computer, you can simply connect the USB port of the SD7K to a USB port of your computer using a single USB A-B cable.
2. Setup your sequencer to respond to MIDI Clock Sync.
3. Press the Start/Stop button to start the sequence from the top.
4. Press the Start/Stop button again to stop the sequence

NOTE: You can adjust the tempo of your sequencer using the Tempo buttons on the SD7K.


### Using a sequencer to record your SD7K drum performance

Using the MIDI IN/OUT or USB connections with a MIDI sequencer allows you to record your performance on the SD7K pads and play it back with the same voices.

1. Connect the MIDI Out of the SD7K to the MIDI In of your sequencer, and the MIDI Out of your sequencer to the MIDI In of the SD7K. If you are using a software sequencer on a computer, you can simply connect the USB port of the SD7K to a USB port of your computer using a single USB A-B cable.
2. Setup the active track of your sequencer on Channel 10.
3. Activate RECORD on your sequencer.
4. Play the pads of your SD7K.
5. Stop recording.
6. Locate your sequencer to the start of the recording.
7. Playback the recorded sequence.
8. The SD7K will play the same voices that were used during recording.

#### NOTES:

1. To maintain the same voice parameters (level, pan, tuning), you should select the same Kit for playback as the Kit that was active when recording.
2. To capture and correctly reproduce the timing of your performance, make sure that the Quantize function of your sequencer is turned off.
3. If your sequencer has a Soft-Thru feature, you should set the SD7K to "Local Off" mode in the Utility menu. If your sequencer does not have a Soft-Thru feature, you should leave the SD7K in its "Local On" default mode.



# VOICE LIST

#	Name	#	Name	#	Name	#	Name
<b>Acoustic Bass Drum</b>		<b>Acoustic Snare Drum</b>		<b>Electronic Snare Drum</b>		<b>Acoustic Tom</b>	
1	Standard Acoustic Kick 1	38	Snare Edge w/Rim	80	House Snare	103	Open Tom 1
2	Standard Acoustic Kick 2	39	Standard Snare	81	House Clap	104	Open Tom 2
3	Rock Acoustic Kick 1	40	Snare Cross Stick	82	House Effect Snare	105	Open Tom 3
4	Rock Acoustic Kick 2	41	12" Snare	83	Techno Snare	106	Open Tom 4
5	Jazz Acoustic Kick 1	42	Rock Snare 1	84	Dance Beat snare	107	Open Tom 5
6	Jazz Acoustic Kick 2	43	Rock Snare 1 Edge	85	Staccato Snare	108	Rock Tom 1
7	26" Large Acoustic Kick	44	Rock Snare 2	86	TR808 Snare	109	Rock Tom 2
8	20" Funk Acoustic Kick	45	Small Room Snare	87	TR909 Snare	110	Rock Tom 3
9	20" Hip Hop Acoustic Kick	46	Large Room Snare	88	Electric Snare	111	Rock Tom 4
10	20" Tight Acoustic Kick	47	Jazz Snare 1	89	Reverse Snare	112	Big Tom 1
11	24" Loose Acoustic Kick	48	Jazz Snare Brush Edge	90	Junkyard Snare	113	Big Tom 2
12	20" Small Acoustic Kick	49	Jazz Snare Brush	91	Junkyard EFX	114	Big Tom 3
13	22" 1971 Kick	50	Jazz Snare 2	92	Noise Snare	115	Big Tom 4
14	20" Deep Kick	51	Jazz Piccolo Snare	93	Jing Snare	116	Big Tom 5
15	'90's Kick	52	Big Band Snare	94	Guak Snare	117	Power Tom 1
16	Metal Kick	53	Deep Fusion Snare	95	Voice 1	118	Power Tom 2
17	Orchestra Bass Drum	54	Effect Snare 1	96	Voice 2	119	Power Tom 3
18	Bass Drum Roll	55	Effect Snare 2	97	Cartoon Punch	120	Power Tom 4
<b>Electronic Bass Drum</b>		56	Hip Hop Snare	98	Simmons Snare 1	121	Funk Tom 1
19	House Kick 1	57	'60's Snare Edge	99	Simmons Snare 2	122	Funk Tom 2
20	House Kick 2	58	'60's Snare	100	Simmons Snare 3	123	Funk Tom 3
21	House Kick 3	59	506 Snare	101	Simmons Snare 4	124	Fusion Tom 1
22	TR808 Kick	60	506 Snare 2	102	Simmons Clap	125	Fusion Tom 2
23	TR909 Kick	61	506 Low Snare			126	Fusion Tom 3
24	Space Kick	62	506 Low Snare 2			127	'69 Tom 1
25	Filter Kick	63	'69 Snare			128	'69 Tom 2
26	Reverse Kick	64	Pong Snare			129	'69 Tom 3
27	Techno Kick	65	Filter Snare			130	'71 Tom 1
28	Voice Kick	66	Wood Snare 1			131	'71 Tom 2
29	Low Fi Kick	67	Wood Snare 2			132	'71 Tom 3
30	Junkyard Kick	68	Deep Maple Snare			133	Vintage Tom 1
31	Disco Kick	69	Studio Snare			134	Vintage Tom 2
32	Industrial Kick	70	Distant Power Snare			135	Vintage Tom 3
33	Cartoon Kick	71	Crackless Snare			136	Hip Hop Tom 1
34	Simmons Kick 1	72	Gunshot Snare 1			137	Hip Hop Tom 2
35	Simmons Kick 2	73	Gunshot Snare 2			138	Hip Hop Tom 3
36	Simmons Kick 3	74	Metal Snare			139	Hip Hop Tom 4
37	Simmons Kick 4	75	Brush Swirl Snare			140	Hip Hop Tom 5
		76	Brush Strike Snare			141	Hip Hop Tom 6
		77	Brush Edge Snare			142	Brush Tom 1
		78	Light Brush Snare			143	Brush Tom 2
		79	Light Long Brush Snare			144	Brush Tom 3
						145	Brush Tom 4

## VOICE LIST CONT...

#	Name	#	Name	#	Name	#	Name
<b>Electric Tom</b>		<b>Cymbal</b>		<b>Hi-Hat</b>		<b>Percussion</b>	
146	TR808 Tom 1	194	Standard 20" Ride	237	Standard Hats 1	253	Metronome Bell
147	TR808 Tom 2	195	Standard 22" Ride	238	Standard Hats 2	254	Metronome Click
148	TR808 Tom 3	196	Standard Ride Bell	239	Quick Hats	255	Scratch
149	TR808 Tom 4	197	Rock Ride	240	Rock Hats	256	Scratch Push
150	TR808 Tom 5	198	Ride Edge	241	Pop Hats	257	DJ EFX
151	TR808 Tom 6	199	Rock Bell	242	Brush Hats	258	HiQ Zap
152	Electric 1 Tom 1	200	Dry Ride	243	'60's Hats	259	Ding Bell
153	Electric 1 Tom 2	201	Dry Ride Bell	244	Mini Hats	260	Finger Snaps
154	Electric 1 Tom 3	202	Rivet Ride	245	House Hats	261	Standard Clap
155	Electric 1 Tom 4	203	Vintage Ride	246	TR808 Hats	262	Tambourine
156	Electric 2 Tom 1	204	'60's Ride	247	TR909 Hats	263	Vibraslap
157	Electric 2 Tom 2	205	Clean Pop Ride	248	Cartoon Hats	264	Agogo Low
158	Electric 2 Tom 3	206	Pop Ride Edge	249	Voice Hats	265	Agogo High
159	Electric 2 Tom 4	207	Light Flat Ride	250	Junkyard Hats	266	Bell Tree
160	Electric 3 Tom 1	208	Flat Ride	251	Noise Hats	267	Bongo High
161	Electric 3 Tom 2	209	Junkyard Break	252	Bass Hats	268	Bongo Low
162	Electric 3 Tom 3	210	Junkyard Metal			269	Shaker
163	TR909 Tom 1	211	Junkyard Spring			270	Conga Slap Low
164	TR909 Tom 2	212	Industrial Short			271	Conga Slap High
165	TR909 Tom 3	213	Industrial Long			272	Elect Conga Low
166	Spike Jr	214	Glass China			273	Open Conga
167	Spike	215	Standard Crash			274	Conga Slap
168	Look At Da Birdie	216	China 1			275	Cowbell
169	Junkyard 1	217	Splash			276	Timbale Hi
170	Junkyard 2	218	Crystal Crash			277	Timbale Low
171	Junkyard 3	219	China 2			278	Timpani High
172	Noise Tom 1	220	China Low			279	Timpani Low
173	Noise Tom 2	221	Orchestra Hit			280	Open Tabla High
174	Noise Tom 3	222	Orchestra Cymbals			281	Open Tabla Low
175	Voice Tom 1	223	Gong 1			282	Slap Tabla
176	Voice Tom 2	224	Gong 2			283	Mute Tabla slap
177	Voice Tom 3	225	Water Gong			284	Cabasa
178	Submarine Tom 1	226	Reverse Cymbal			285	Maracas
179	Submarine Tom 2	227	TR808 Cymbal 1			286	Short Whistle
180	Submarine Tom 3	228	TR808 Cymbal 2			287	Guiro Short
181	Simmons V1 Tom 1	229	TR808 Cymbal 3			288	Guiro Long
182	Simmons V1 Tom 2	230	TR909 Cymbal 1			289	Claves
183	Simmons V1 Tom 3	231	Junkyard Cymbal 1			290	Woodblock
184	Simmons V2 Tom 1	232	Junkyard Cymbal 2			291	Cuica Muted
185	Simmons V2 Tom 2	233	Cymbal Effect 1			292	Cuica Open
186	Simmons V2 Tom 3	234	Cymbal Effect 2			293	Triangle Muted
187	Simmons V3 Tom 1	235	Laser Ray			294	Triangle Open
188	Simmons V3 Tom 2	236	Drive By			295	Sleigh Bells
189	Simmons V3 Tom 3					296	Wind Chimes
190	Simmons V4 Tom 1					297	Castanets
191	Simmons V4 Tom 2					298	Surdo Muted
192	Simmons V4 Tom 3					299	Surdo Open
193	Simmons Bend Tom					300	Lotus Drum

# DRUM KIT LIST

#	Preset Kit	#	Preset Kit	#	Preset Kit	#	Preset Kit
Factory Preset Kits		Factory Preset Kits		User Programmable Kits		User Programmable Kits	
1	Rock	11	'60's	21	User 1 - '70's	31	(User 11 - Rock)
2	Standard 1	12	Simmons 1	22	User 2 - Latin Percussion	32	(User 12 - Standard 1)
3	Room	13	Simmons 2	23	User 3 - Tablas	33	(User 13 - Room)
4	Standard 2	14	Funk	24	User 4 - DJ EFX	34	(User 14 - Standard 2)
5	Hip-hop	15	Jazz Latin	25	User 5 - 909	35	(User 15 - Hip-Hop)
6	Electronic	16	Percussions	26	User 6 - Industry	36	(User 16 - Electronic)
7	808	17	Metal	27	User 7 - Cartoon	37	(User 17 - 808)
8	House	18	Orchestral	28	User 8 - Voice	38	(User 18 - House)
9	Fusion	19	Studio	29	User 9 - Simmons 3	39	(User 19 - Fusion)
10	Brush	20	Junkyard	30	User 10 - Simmons 4	40	(User 20 - Brush)
						41	(User 21 - 60's)
						42	(User 22 - Simmons 1)
						43	(User 23 - Simmons 2)
						44	(User 24 - Funk)
						45	(User 25 - Jazz Latin)
						46	(User 26 - Percussions)
						47	(User 27 - Metal)
						48	(User 28 - Orchestral)
						49	(User 29 - Studio)
						50	(User 30 - Junkyard)

# SONG LIST

#	Name	#	Name	#	Name	#	Name
1	Funk 1	15	Drum 'n Bass	29	Rhumba	43	Slow Rock
2	Fusion 1	16	Jazz	30	Shuffle	44	R&B 1
3	Latin Jazz	17	Bossa	31	Swing	45	R&B 2
4	Dance	18	Pop	32	Blues 1	46	6/8 R&B
5	Big Band	19	Rock 'n Roll 1	33	Blues 2	47	Pop Rock
6	Slow Fusion	20	House	34	Fusion2	48	Hard Rock
7	Samba	21	Hip Hop	35	Funk 2	49	Pop Ballad
8	Modern Jazz	22	6/8 Ballad	36	Acid Fusion	50	New Age
9	Country	23	Ballad 1	37	Folk Pop		
10	Reggae	24	Boogie	38	Latin		
11	Salsa	25	Punk	39	Ballad 2		
12	Bluegrass	26	Rock 'n Roll 2	40	Disco		
13	Mambo	27	Metal	41	8 Beat		
14	Beguine	28	16 Beat	42	Funk 3		

# GENERAL MIDI VOICE LIST

## PIANO

001	Acoustic Grand Piano
002	Bright Acoustic Piano
003	Electric Grand Piano
004	Honky-Tonk Piano
005	Electric Piano 1
006	Electric Piano 2
007	Harpsichord
008	Clavichord

## CHROMATIC PERCUSSION

009	Celesta
010	Glockenspiel
011	Music box
012	Vibraphone
013	Marimba
014	Xylophone
015	Tubular Bells
016	Dulcimer

## ORGAN

017	Drawbar Organ
018	Percussive Organ
019	Rock Organ
020	Church Organ
021	Reed Organ
022	Accordion
023	Harmonica
024	Tango Accordion

## GUITAR

025	Acoustic Nylon Guitar
026	Acoustic Steel Guitar
027	Electric Jazz Guitar
028	Electric Clean Guitar
029	Electric Muted Guitar
030	Overdriven Guitar
031	Distortion Guitar
032	Guitar Harmonics

## BASS

033	Acoustic Bass
034	Electric Bass (finger)
035	Electric Bass (pick)
036	Fretless Bass
037	Slap Bass 1
038	Slap Bass 2
039	Synth Bass 1
040	Synth Bass 2

## STRINGS

041	Violin
042	Viola
043	Cello
044	Contrabass
045	Tremolo Strings
046	Pizzicato Strings
047	Orchestral Harp
048	Timpani

## ENSEMBLE

049	String Ensemble 1
050	String Ensemble 2
051	Synth Strings 1
052	Synth Strings 2
053	Choir "Aahs"
054	Voice "Oohs"
055	Synth Voice
056	Orchestra Hit

## BRASS

057	Trumpet
058	Trombone
059	Tuba
060	Muted Trumpet
061	French Horn
062	Brass Section
063	Synth Brass 1
064	Synth Brass 2

## REED

065	Soprano Sax
066	Alto Sax
067	Tenor Sax
068	Baritone Sax
069	Oboe
070	English Horn
071	Bassoon
072	Clarinet

## PIPE

073	Piccolo
074	Flute
075	Recorder
076	Pan Flute
077	Bottle Blow
078	Shakuhachi
079	Whistle
080	Ocarina

## SYNTH LEAD

081	Lead 1 (square)
082	Lead 2 (sawtooth)
083	Lead 3 (caliope lead)
084	Lead 4 (chiff lead)
085	Lead 5 (charang)
086	Lead 6 (voice)
087	Lead 7 (fifths)
088	Lead 8 (bass + lead)

## SYNTH PAD

089	Pad 1 (new age)
090	Pad 2 (warm)
091	Pad 3 (polysynth)
092	Pad 4 (choir)
093	Pad 5 (bowed)
094	Pad 6 (metallic)
095	Pad 7 (halo)
096	Pad 8 (sweep)

## SYNTH EFFECT

097	FX 1 (rain)
098	FX 2 (soundtrack)
099	FX 3 (crystal)
100	FX 4 (atmosphere)
101	FX 5 (brightness)
102	FX 6 (goblins)
103	FX 7 (echoes)
104	FX 8 (sci-fi)

## ETHNIC

105	Sitar
106	Banjo
107	Shamisen
108	Koto
109	Kalimba
110	Bagpipe
111	Fiddle
112	Shanai

## PERCUSSIVE

113	Tinkle Bell
114	Agogo
115	Steel Drums
116	Woodblock
117	Taiko Drum
118	Melodic Tom
119	Synth Drum
120	Reverse Cymbal

## SOUND EFFECT

121	Guitar Fret Noise
122	Breath Noise
123	Seashore
124	Bird Tweet
125	Telephone Ring
126	Helicopter
127	Applause
128	Gunshot

## PERCUSSION SET LIST

#	Key	Standard	Room	Rock	Electronic
Ch 10 PC Ch 9,16 PC		1 1,5	2 9	3 17,18	4 25
27	D#1	High Q	←	←	←
28	E 1	Slap	←	←	←
29	F 1	Scratch Push	←	←	←
30	F#1	Scratch Pull	←	←	←
31	G 1	Sticks	←	←	←
32	G#1	Square Click	←	←	←
33	A 1	Metronome Click	←	←	←
34	A#1	Metronome Bell	←	←	←
35	B 1	Acoustic Bass Drum	Bass Drum 2	Acoustic Bass Drum 2	Acoustic Bass Drum
36	C 2	Bass Drum 1	Rock Kick Drum	Rock Kick Drum	El Kick Drum
37	C#2	Side Stick	←	←	←
38	D 2	Acoustic Snare	Snare Drum 2	Acoustic Snare 2	Hard Snare Drum
39	D#2	Hand Clap	←	←	←
40	E 2	Hard Snare Drum	Hard Snare Drum	Acoustic Snare 3	Electric Snare
41	F 2	Low Floor Tom	Room Low Tom 2	Rock Low Tom 2	El Low Tom 2
42	F#2	Closed Hi-Hat	Closed Hi-Hat 2	Closed Hi-Hat 2	Closed Hi-Hat 3
43	G 2	High Floor Tom	Room Low Tom 1	Rock Low Tom 1	El Low Tom 1
44	G#2	Pedal Hi-Hat	Pedal Hi-Hat 2	Pedal Hi-Hat 2	Pedal Hi-Hat 3
45	A 2	Low Tom	Room Mid Tom 2	Rock Mid Tom 2	El Mid Tom 2
46	A#2	Open Hi-Hat	Open Hi-Hat 2	Open Hi-Hat 2	Open Hi-Hat 3
47	B 2	Low-Mid Tom	Room Mid Tom 1	Rock Mid Tom 1	El Mid Tom 1
48	C 3	Hi-Mid Tom	Room Hi Tom 2	Rock Hi Tom 2	El Hi Tom 2
49	C#3	Crash Cymbal 1	←	←	←
50	D 3	High Tom	Room Hi Tom 1	Rock Hi Tom 1	El Hi Tom 1
51	D#3	Ride Cymbal 1	Ride Cymbal 2	Ride Cymbal 2	←
52	E 3	Chinese Cymbal	Chinese Cymbal 2	Chinese Cymbal 2	←
53	F 3	Ride Bell	Ride Bell 2	Ride Bell 2	←
54	F#3	Tambourine	←	←	←
55	G 3	Splash Cymbal	Splash Cymbal 2	Splash Cymbal 2	←
56	G#3	Cowbell	Cowbell 2	Cowbell 2	←
57	A 3	Crash Cymbal 2	←	←	←
58	A#3	Vibraslap	←	←	←
59	B 3	Ride Cymbal 2	←	←	←
60	C 4	Hi Bongo	←	←	←
61	C#4	Low Bongo	←	←	←
62	D 4	Mute Hi Conga	←	←	←
63	D#4	Open Hi Conga	←	←	←
64	E 4	Low Conga	←	←	←
65	F 4	High Timbale	←	←	←
66	F#4	Low Timbale	←	←	←
67	G 4	High Agogo	←	←	←
68	G#4	Low Agogo	←	←	←
69	A 4	Cabasa	←	←	←
70	A#4	Maracas	←	←	←
71	B 4	Short Whistle	←	←	←
72	C 5	Long Whistle	←	←	←
73	C#5	Short Guiro	←	←	←
74	D 5	Long Guiro	←	←	←
75	D#5	Claves	←	←	←
76	E 5	Hi Wood Block	←	←	←
77	F 5	Low Wood Block	←	←	←
78	F#5	Mute Cuica	←	←	←
79	G 5	Open Cuica	←	←	←
80	G#5	Mute Triangle	←	←	←
81	A 5	Open Triangle	←	←	←
82	A#5	Shaker	←	←	←
83	B 5	Jingle Bell	←	←	←
84	C 6	Belltrees	←	←	←
85	C#6	Castanets	←	←	←
86	D 6	Mute Surdo	←	←	←
87	D#6	Open Surdo	←	←	←



## PERCUSSION SET LIST CONT...

#	Key	808	Jazz	Brush	Orchestra	Effects
Ch 10 PC Ch 9,16 PC		5 26	6 33	7 41	8 49	N/A 57
27	D#1	←	←	←	Closed Hi-Hat 2	Buzz
28	E 1	←	←	←	Pedal Hi-Hat	Gong
29	F 1	←	←	←	Open Hi-Hat 2	Scratch FX1
30	F#1	←	←	←	Ride Cymbal 1	Scratch FX2
31	G 1	←	←	←	←	Scratch FX3
32	G#1	←	←	←	←	Scratch FX4
33	A 1	←	←	←	←	Gtr.Cut Noise
34	A#1	←	←	←	←	Gtr.Cut Noise 2 (up)
35	B 1	Acoustic Bass Drum 2	Jazz Kick 2	Jazz Kick 2	Concert BD 2	Muted Dist.Gtr. 1
36	C 2	808 Kick Drum	Jazz Kick 1	Jazz Kick 1	Concert BD 1	Muted Dist.Gtr. 2
37	C#2	←	←	←	←	Dist.Gtr. Slide 1
38	D 2	808 Snare Drum	Jazz Snare Drum	Jazz Snare Drum	Concert SD	Dist.Gtr. Slide 2
39	D#2	←	←	Hand Clap	Castanets	High Q
40	E 2	Hard Snare Drum	Hard Snare Drum	Brush Slap	Concert SD	Slap
41	F 2	808 Low Tom 2	Jazz Low Tom 2	Brush Low Tom 2	Timpani F	Scratch Push
42	F#2	808 Closed Hi-Hat	Closed Hi-Hat 2	←	Timpani F#	Scratch Pull
43	G 2	808 Low Tom 1	Jazz Low Tom 1	Brush Low Tom 1	Timpani G	Sticks
44	G#2	808 Pedal Hi-Hat	Pedal Hi-Hat 2	←	Timpani G#	Square Click
45	A 2	808 Mid Tom 2	Jazz Mid Tom 2	Brush Mid Tom 2	Timpani A	Metronome Click
46	A#2	808 Open Hi-Hat	Open Hi-Hat 2	←	Timpani A#	Metronome Bell
47	B 2	808 Mid Tom 1	Jazz Mid Tom 1	Brush Mid Tom 1	Timpani B	Guitar Slide
48	C 3	808 Hi Tom 2	Jazz Hi Tom 2	Brush Hi Tom 2	Timpani C	Gtr.Cut Noise1(down)
49	C#3	808 Cymbal	←	←	Timpani C#	Gtr.Cut Noise 2 (up)
50	D 3	808 Hi Tom 1	Jazz Tom 1	Brush Hi Tom 1	Timpani D	Gtr.Cut Noise 3
51	D#3	←	←	←	Timpani D#	Key Click
52	E 3	←	←	←	Timpani E	Laugh
53	F 3	←	←	Rivet Ride	Timpani F	Scream
54	F#3	←	←	←	←	Punch
55	G 3	←	Splash Cymbal 3	Splash Cymbal 3	←	Heart Beat
56	G#3	←	←	←	←	Footstep1
57	A 3	←	←	←	Concert Cymbal 2	Footstep2
58	A#3	←	←	←	←	Applause
59	B 3	←	←	←	Concert Cymbal 1	Door Creak
60	C 4	←	←	←	←	Door Slam
61	C#4	←	←	←	←	Scratch
62	D 4	808 Mute Hi Conga	←	←	←	Wind Chine
63	D#4	808 Open Hi Conga	←	←	←	Car Engine start
64	E 4	808 Low Conga	←	←	←	Car Break
65	F 4	←	←	←	←	Car Pass By
66	F#4	←	←	←	←	Gun Shot
67	G 4	←	←	←	←	Crickets
68	G#4	←	←	←	←	Train
69	A 4	←	←	←	←	Noise
70	A#4	808 Maracas	←	←	←	Helicopter
71	B 4	←	←	←	←	Industrial Noise
72	C 5	←	←	←	←	Gun Shot
73	C#5	←	←	←	←	Machine Gun
74	D 5	←	←	←	←	Laser Gun
75	D#5	808 Claves	←	←	←	Explosion
76	E 5	←	←	←	←	Dog Bark
77	F 5	←	←	←	←	Horse Gallop
78	F#5	←	←	←	←	Birds Chirping
79	G 5	←	←	←	←	Rain
80	G#5	←	←	←	←	Thunder
81	A 5	←	←	←	←	Wind
82	A#5	←	←	←	←	Sea Shore
83	B 5	←	←	←	←	Stream
84	C 6	←	←	←	←	Bubbles
85	C#6	←	←	←	←	Cat
86	D 6	←	←	←	←	Bird
87	D#6	←	←	←	←	Dog

## MIDI IMPLEMENTATION CHART

Function		Transmitted	Recognized	Remarks
Basic Channel	Default	10 ch	1-16	
	Changed	X	X	
Mode	Default	X	X	
	Messages	X	X	
	Altered	*****	*****	
Note Number:	True voice	0-127	0-127	
		*****	0-127	
Velocity	Note on	0 (99H, V=1-127)	0 (9nH, V=1-127)	
	Note off	0 (99H, V=0)	0 (8nH or 9nH, V=0)	
After Touch	Key's	X	X	
	Channel's	X	X	
Pitch Bend		X	0	
Control Change	0	X	0	Bank Select
	1	X	0	Modulation
	4	0	0	Foot Controller
	5	X	0	Portamento Time
	6	X	0	Data Entry
	7	X	0	Volume
	10	X	0	Pan
	11	X	0	Expression
	64	X	0	Sustain Pedal
	65	X	0	Portamento ON/OFF
	66	X	0	Sostenuto Pedal
	67	X	0	Soft Pedal
	80	X	0	Reverb Program
	81	X	0	Chorus Program
	91	X	0	Reverb Level
	93	X	0	Chorus Level
	100, 101	X	0	RPN LSB, MSB*
	120	X	0	All Sound OFF
	121	X	0	Reset All Controller
	123	X	0	All Notes OFF
Program Change		0	0	
System Exclusive		X	0	
System Common	: Song Position	X	X	
	: Song Select	X	X	
	: Tune	X	X	
System Real Time	: Clock	0	X	
	: Commands	0	X	START and STOP only
Aux	: Local ON/OFF	X	X	
	: All Notes OFF	X	X	
Messages	: Active Sense	0	X	
	: Reset	X	X	

0: YES  
X: NO

\* Valid RPN # 0,1,2

Two (2) Year Limited Warranty

Subject to the limitations set forth below, Simmons® hereby represents and warrants that the components of this product shall be free from defects in workmanship and materials, including implied warranties of merchantability or fitness for a particular purpose, subject to normal use and service, for two (2) year to the original owner from the date of purchase.

Retailer and manufacturer shall not be liable for damages based upon inconvenience, loss of use of product, loss of time, interrupted operation or commercial loss or any other incidental or consequential damages including but not limited to lost profits, downtime, goodwill, damage to or replacement of equipment and property, and any costs of recovering, reprogramming, or reproducing any program or data stored in equipment that is used with Simmons® products. This guarantee gives you specific legal rights. You may have other legal rights which vary from state to state. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

Simmons  
P.O. Box 5111  
Thousand Oaks, CA 91359-5111

All trademarks and registered trademarks mentioned herein are recognized as the property of their respective holders.  
Made in China.

0704-7910



[WWW.SIMMONSDRUMS.NET](http://WWW.SIMMONSDRUMS.NET)