

Thank you for purchasing the Simmons KP2 Mesh Kick Drum. This pad adds a great-feeling kick drum to your electronic drum kit or multipad, and works with nearly any beater pedal.

1. Remove the kick pad from the packaging.
2. Place the pad on a drum rug under your kit. The hook-and-loop fasteners and non-slip spikes work best on a drum rug surface and may damage a wood floor.
3. Attach a standard kick beater pedal to the bottom of the pad (not included.)
 - **Important Note: Use a plastic beater with this or any other mesh pad. A felt beater may damage the pad over time.**
4. Connect a 1/4" cable from the output of your pad to the input of your drum module or multipad.
5. You may need to adjust the sensitivity settings on your drum module for best performance. On the SD550 module, try setting Sensitivity to "10" and curve to "Normal".

