



Simmons SD1200 Firmware Release Notes

To update your SD1200 module:

Note: This will reset any settings and user kits you have in the module

1. Connect a USB cable from your computer to the module.
2. Open *Simmons Flash Upload* for Mac or Windows, available from the [Simmons website](#).
3. The software should alert you that the module is connected and will report the current firmware version.
4. Click the Browse button in the application, select the ROM file that you downloaded. The update file needs to be Un-Zipped and should end with “.bin”
5. Click Update.
6. When the update is complete, disconnect the power to the module and then plug it back in.
7. Hold + and – while powering on to reset the module.

Changes in Firmware Version 20200730:

- The MIDI note numbers for trigger pads are now programmable. Press Utility then F5 to access this feature.
- The MIDI Controller number used for the hi-hat controller is now programmable. Press Utility then F1 to find this parameter
- Previously, local off mode would still trigger patterns. This has been fixed.
- The default crosstalk setting for the ride cymbal has been adjusted.